New Model Showerdrains

Installation-instruction

Box Contents:

- Shower Drain
- Waterproof connection
- Set adjustable parts

1

Necessary materials:

- Sandpaper
- Spirit level
- Tape
- Degreasing agent
- Silicone sealant

2

Roughten the flange:

- We recommend to use the sandpaper to roughen the surface of the side and bottom sections of the drain, then degreasing agent to achieve better adhesion to the floor.

3

Substance removes:

- Make sure that no impurities (motar , etc) can get into drain during the assembly and installation work.

4

Degreasing:

- To degrease the fringe around(for example: use acetone) after the substance has been removed.

5

Extrude adhesive on fringe

- Put adhesive on the fringe all around of the drain. Note: the adhesive applying must be consecutive, no lacks to avoid water infiltration possible.

www.mondeway.com

6

Paste waterproof on fringe:

- Put the waterproof on the fringe smoothly. Make sure they stick together closely.
- Push the waterproof well and check if there lacking adhesive.
- Keep the waterproof unmoved untill the adhesive solidified (minimum 24 hours, keep the space warm if possible), so that the waterproof and drain cannot be separate.

7

Extrude adhesive on Floor title / Waterproof:

- If the waterproof stick on drain fringes steady, then extrude adhesive on waterproof again, consecutive and allover.

8

Paste floor title on waterproof:

- For the purpose to paste floor title on the waterproof which full of adhesive already, push the floor title on.
- Take care that there no discontinuances / stops of adhesive. Push them together well.
- Keep the floor title unmoved untill the adhesive solidified (minimum 24 hours, keep the space warm if possible), so that the floor title and waterproof cannot be separate.

9

Landing edge

- Make the edge to edge closely and joint them together smoothly

10

Joint between Drain and Floor title

- Fill the joint between the floor tile and the edge of drain with adhesive, filling-in and smoothing. Brush and make the joint nicely.
- Fill up the adhesive to the joint between floor titles and make the joint nicely.